

Part Number:
1990535

Models:
Interceptor Bear 650 (all models)
Interceptor (648cc, all models)


WARNING: Royal Enfield genuine accessories are designed to fit only the specific Royal Enfield motorcycle(s) that are specified above. They should not be fitted to any other type of motorcycle. Pay particular attention to the warnings and cautions contained in this instruction, failure to do so may result in an incorrect installation of the accessory which could result in an unsafe riding condition and possible accident. If in any doubt always seek help from your authorised Royal Enfield dealer.

WARNING: Before starting any accessory kit installation ensure the motorcycle is supported in a stable condition. Failure to support the motorcycle correctly could lead to motorcycle damage or personal injury.

WARNING: All fixings must be tightened to the torque values specified in this instruction. Failure to tighten fixings to the correct torque could result in an unsafe riding condition and possible accident

CAUTION: Care should be taken when fitting any accessory kit. Incorrect handling of kit components or the use of incorrect tools could lead to component or motorcycle damage.


NOTE: The content of this instruction is subject to change at any time without notice or liability. Royal Enfield reserves the right to revise the information presented at any time.




Item	Description	Qty
1	Tank pad, left hand	1
2	Tank pad, right hand	1
3	Cleaning wipe	1

1 Using the supplied cleaning wipe, clean the fuel tank (1) on the left side in the indented area shown (2).

Note: The minimum application temperature for the adhesive is 15°C.




2 Repeat the cleaning for the right side in the area shown (1).




3 Take a left tank pad (1) (note there is an 'L' on the red plastic of the left tank pad) and remove the adhesive backing layer. Carefully align the tank pad, 22mm offset from the fuel tank radius (2), and 24mm offset from the lower tank edge (3). The tank pad will sit fully within the fuel tank indent.


Apply firm and even hand pressure across the whole tank pad surface, starting from the centre to avoid air traps. Hold for one minute to make sure a good bond is achieved.



4 Repeat step 3 for the right side tank pad (1). Check both sides for air gaps and press in these areas if applicable.



5 Leave the tank pads for 24hrs to cure in an ambient temperature between 15°C and 30°C before use.



24hours



WARNING: After fitting any genuine Royal Enfield accessory always ride the motorcycle with caution and allow time to become familiar with any change in the motorcycle handling characteristics. Failure to become familiar with any change in the motorcycle handling characteristics may cause the motorcycle to become unstable and result in an accident.